





Emergency Exit/Pushout Window Assemblies

Replacement emergency pushout window assemblies for Thomas Built Buses.



Product Highlights

Feature or benefit

- Thomas Built Buses replacement windows offers a wide variety of OEM window options to keep your bus safe and up to current specifications. All windows meet current FMVSS and CMVSS standards.

Top Movers - Spectal Pushout Window Assemblies

Material Number	Material Description
TBB 185251	WDO P/O, RS TEMP TINT, 12" STOP, C2 VERTICAL
TBB 185235	WDO P/O, LS TEMP TINT, 12" STOP, C2 VERTICAL

TBB 185255	WDO P/O, RS LAM TINT, 12" STOP, C2 VERTICAL
TBB 185239	WDO P/O, LS LAM TINT, 12" STOP, C2 VERTICAL
TBB 122173	WDO PO HORZ TEMP CLR LS 12 STOP
TBB 122189	WDO PO HORZ TEMP CLR RS 12 STOP
TBB 122177	WDO P/O HORZ TEMP TNT LS 12 STOPS
TBB 122193	WDO P/O HORZ TEMP TNT RS 12 STOPS
TBB 122181	WDO PO HORZ LAM CLR LS 12 STOP
TBB 122197	WDO PO HORZ LAM CLR RS 12 STOP
TBB 122185	WDO P/O HORZ LAM TNT LS 12 STOPS
TBB 122201	WDO P/O HORZ LAM TNT RS 12 STOPS

Warranty Information

The warranty period is 1 Year from date of purchase/unlimited mileage

Last updated: Friday, 28 July 2023 03:14 PM

[^Back to Top](#)

Copyright © Daimler Truck North America LLC. [Privacy Statement, Legal Notices and Terms \(https://daimler-trucksnorthamerica.com/privacy-policy\)](https://daimler-trucksnorthamerica.com/privacy-policy).

All rights reserved. Daimler Truck North America LLC is a [Daimler \(http://www.daimler.com/\)](http://www.daimler.com/) company.